C-band Femtosecond Fiber Laser





Applications

- Telecommunication components characterization
- Optical high speed sampling
- Terahertz radiation
- Optical switching
- Materials characterization
- Optical metrology

Features

- Wavelength tunable from 1535 to 1560 nm
- Pulse width selectable from 0.1 to 0.5 ps
- Average power from 1 mW to 200 mW
- Pulse width tunability
- Near transform-limited output
- Minimal pulse pedestal
- Low timing jitter
- RF synchronization output
- Turnkey operation


The C-band bench top femtosecond fiber laser (FPL) is a passively mode-locked fiber laser that utilizes a saturable absorber to deliver excellent stability and reliability, with turnkey operation. Along with a portable design, the FPL series offers user-friendly front panel control knobs for flexible adjustment of wavelength, pulse width, and output power. Both tunable (throughout the C-band) and fixed wavelength versions are available. The pulse width is factory selectable from 0.1 to 0.5 ps, with near transform-limited pulse shape and a better than 20 dB pedestal. The timing jitter is as low as 60 fs. The repetition rate can be specified from 10 to 100 MHz with either a polarization-maintaining (PM) or non-PM fiber output. With up to 200 mW output power, the FPL series is the most economical solution for applications requiring low power, such as seeding amplifier systems. An RF synchronization output is provided as a trigger signal.


Mendocino 1550 nm Technical Specifications

Specifications	Low Power (1 mW - 4 mW)	Medium Power (10 mW - 200 mW)
Central Wavelength (nm)	1550 (option: 1535-1560 tunable)	1550
Average Power (mW)	1 - 4	10 - 200
Pulse Width (ps) *	0.5	0.1
Repetition Rate (MHz)	Typicla 20 - 50 (10 - 100 available)	
Peak Output Power (W)	100 - 400	1 k - 10 k
Spectral Width (nm)	5	30 - 40
Timing Jitter (fs)	60 (carrier offset 100 Hz - 1 MHz)	
Fiber Type	SMF-28 or PM fiber	
Polarization Extinction Ratio (dB)	20	
Operating Temp (°C)	10 ~ 35	
Operating Voltage	Desktop: 85 - 264 VAC Module: 5 VDC	
Dimensions (cm)	Desktop: 34(w) x 40(d) x 9(h) Module: 9.5(w)x 12.7(d) x 2.5(h)	Desktop: 34(w) x 40(d) x 9(h) Module: 20.3(w)x 12.7(d) x 4.3(h)

^{*} Up to 15 ps pulse width available; once selected it is tunable by adjusting pump current. A sech² pulse shape (convolution factor of 0.65) is used to determine the pulse width for the second harmonic autocorrelation trace.

Due to our continuous improvement program, specifications are subject to change without notice







上海昊量光电设备有限公司 中国区代理 官网: www.auniontech.com 电话: 185 0177 0670 邮箱: jiabin-wei@auniontech.com 地址: 上海市徐汇区漕宝路 86 号光大会展中心 F 座 3 楼

